

OLEANDER SERIES

INSTALLATION INSTRUCTION



Upon request



PHYSICAL

Body	Die cast Aluminum
Finish	Polyester Powder Coated

OPTICAL

Diffuser	Polycarbonate
Reflector	Polycarbonate
Aiming	355° Rotatable horizontally 325° Adjustable vertically
Beam Angle	15°,24°,36°

ELECTRICAL

Light source	LED CREE
Efficacy	93lm/W
CRI	>80 (>90 available on request)
CCT	3000K-4000K-6000K
Driver	Electronic included 50-60Hz 220-240VAC Non-Dimmable Driver 1-10V dimming or DALI on request
Light source Life	60,000 h

PRODUCT RANGE

	Rated Power(W)	Lumen(lm)	Dimensions(mm)	Cut out Dimensions(mm)
OLEANDER ROUND 1.1	12W	1116lm	Ø90xH80	Ø75mm
OLEANDER ROUND 1.2	20W	1860lm	Ø110xH105	Ø95mm
OLEANDER ROUND 1.3	30W	2790lm	Ø135xH140	Ø115mm
OLEANDER SQUARE 1.1	12W	1116lm	L90xW90xH80	80x75mm
OLEANDER SQUARE 1.2	20W	1860lm	L117xW117xH105	95x90mm
OLEANDER SQUARE 1.3	30W	2790lm	L140xW140xH125	120x115mm
OLEANDER DUAL 1.1	2x12W	2x1116lm	L170xW90xH80	152x75mm
OLEANDER DUAL 1.2	2x15W	2x1400lm	L210xW117xH105	185x95mm
OLEANDER DUAL 1.3	2x20W	2x1860lm	L210xW117xH105	185x95mm
OLEANDER DUAL 1.4	2x30W	2x2790lm	L250xW140xH125	120x225mm

RECESS MOUNTED INSTALLATION

1

Ceiling opening: Please refer to cutout dimensions in the table above.

2

When power is off, connect the light wire.

3

Install the lamp body into the ceiling cutout and make sure it is installed properly.

OLEANDER ROUND



OLEANDER SQUARE



OLEANDER DUAL



SAFETY INSTRUCTIONS:

- Please read this instruction carefully before the commencement of installation and pass it on to the user of the equipment.
- The installation must be carried out by qualified personnel.
- Disconnect the main voltage, before starting the installation work.
- The light source of this luminaire is not replaceable when the light source reaches the end of its useful life, the entire luminaire is substituted.
- This fixture is not suitable for handheld use. It should be mounted in a fixed and safe place.
- Improper handling of the components or the luminaire itself could damage the correct function of this product, thus avoiding the manufacturer's warranty.
- Luminaire is suitable for indoor use.
- BEYOND LIGHTING FACTORY is not responsible for the improper use or modifications made to the product.
- In case the external flexible cable or cord of the fixture is damaged, to avoid danger it should only be replaced by the manufacturer or equivalent qualified personnel.
- For possible malfunctions, the defective products must be disassembled and delivered to the manufacturer company without any intervention. During the dismantling of the product, the cable insulation should not be damaged. Also, the cable should not be cut too close to the product. Enough cable should be left to take out the fixture.
- The report, which will be formed as a result of the tests to be made regarding the malfunction, will be shared with the customer, and if necessary, the product will be delivered back to the customer by eliminating the problems according to the warranty.